



FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

3/20/2018

AGCO, Challenger, Fendt, Massey Ferguson						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
545E	555E	565E	10-22mm Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	74-1/2"	12X28	WPFDS-10Q-280120-156AG-N2215
575E	585E	595E			15X28	WPFDS-10Q-280150-156AG-N2215
MT545BD	MT545BV	MT555BD			13X30	WPFDS-10Q-300130-156AG-N2215
MT555BV	MT555D	MT565			15X30	WPFDS-10Q-300150-156AG-N2215
MT565BD	MT565BV	MT575B			10X34	WPFDS-10Q-340100-156AG-N2215
MT575D	MT585D	MT595			13X34	WPFDS-10Q-340130-156AG-N2215
MT635	MT645*	712			15X34	WPFDS-10Q-340150-156AG-N2215
714	716	718			10X38	WPFDS-10Q-380100-156AG-N2215
720	722	724			12X38	WPFDS-10Q-380120-156AG-N2215
815**	817**	818**				
820**	822**	824**				
826**	828**	6480				
6485	6490	6495				
6497	6499	7480				
7485	7490	7495				
7499	7618	7619				
7620	7622	7624				
7626	7718	7719				
7720	7722	7724				
7726	8220	8240				
8245	8250	8260				
8450	8460	DT200A*				
RT130	RT145					

*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering

**These models need to have hub holes drilled out for larger stud installation.

New studs and hardware are included with this kit.



FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

3/20/2018

AGCO, Challenger, Fendt, Massey Ferguson					
Models	Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number	
				20 or 30" Row Spacing	
DT160 DT180 DT180A	12-22mm Studs on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/2"	12X28	WPFDS-12Q-280120-156AG-N2215	
DT200 DT200A* DT225			15X28	WPFDS-12Q-280150-156AG-N2215	
DT225B DT220A DT240A			13X30	WPFDS-12Q-300130-156AG-N2215	
DT250B DT275B MT645C			15X30	WPFDS-12Q-300150-156AG-N2215	
MT655 MT655C MT655D			10X34	WPFDS-12Q-340100-156AG-N2215	
MT655E MT665 MT665C			13X34	WPFDS-12Q-340130-156AG-N2215	
MT665D MT665E MT675C			15X34	WPFDS-12Q-340150-156AG-N2215	
MT675D MT675E MT685D			10X38	WPFDS-12Q-380100-156AG-N2215	
MT685E 920 922			12X38	WPFDS-12Q-380120-156AG-N2215	
924 926 927					
930 933 936					
939 8270 8280					
8470 8480 8650					
8660 8670 8680					
8690 8727 8730					
8732 8735 8737					

*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering
New studs and hardware are included with this kit.

Case-IH					
Models	Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number	
				20 or 30" Row Spacing	
7110 7120 7130 7140 7150 7210 7220 7230 7240 7250	10-3/4" Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	77-3/4"	12X28	WPFDS-10-280120-156SM-N7516	
			15X28	WPFDS-10-280150-156SM-N7516	
			13X30	WPFDS-10-300130-156SM-N7516	
			15X30	WPFDS-10-300150-156SM-N7516	
			10X34	WPFDS-10-340100-156SM-N7516	
			13X34	WPFDS-10-340130-156SM-N7516	
			15X34	WPFDS-10-340150-156SM-N7516	
			10X38	WPFDS-10-380100-156SM-N7516	
			12X38	WPFDS-10-380120-156SM-N7516	

New studs and hardware are included with this kit.



FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

3/20/2018

Case-IH						
Models		Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number	
					20 or 30" Row Spacing	
8910 8920 8930 8940 8950	10-20mm Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	74-1/2"	12X28	WPFDS-10-280120-156SM-N2015		
			15X28	WPFDS-10-280150-156SM-N2015		
			13X30	WPFDS-10-300130-156SM-N2015		
			15X30	WPFDS-10-300150-156SM-N2015		
			10X34	WPFDS-10-340100-156SM-N2015		
			13X34	WPFDS-10-340130-156SM-N2015		
			15X34	WPFDS-10-340150-156SM-N2015		
			10X38	WPFDS-10-380100-156SM-N2015		
			12X38	WPFDS-10-380120-156SM-N2015		

New studs and hardware are included with this kit.

Case-IH						
Models		Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number	
					20 or 30" Row Spacing	
Magnum 180*	MX180	10-20mm Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	74"	12X28	WPFDS-10-280120-156SM-N2015	
Magnum 190*	MX200			15X28	WPFDS-10-280150-156SM-N2015	
Magnum 200*	MX210*			13X30	WPFDS-10-300130-156SM-N2015	
Magnum 210*	MX215*			15X30	WPFDS-10-300150-156SM-N2015	
Magnum 215*	MX220			10X34	WPFDS-10-340100-156SM-N2015	
Magnum 225*	MX230*			13X34	WPFDS-10-340130-156SM-N2015	
Magnum 235*	MX245*			15X34	WPFDS-10-340150-156SM-N2015	
Magnum 245*				10X38	WPFDS-10-380100-156SM-N2015	
				12X38	WPFDS-10-380120-156SM-N2015	

*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering

New studs and hardware are included with this kit.



FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

3/20/2018

Case-IH					
Models		Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
					20 or 30" Row Spacing
Magnum 180*	MX210*	12-20mm Studs on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/4"	12X28	WPFDS-12-280120-156SM-N2015
Magnum 190*	MX215*			15X28	WPFDS-12-280150-156SM-N2015
Magnum 200*	MD230*			13X30	WPFDS-12-300130-156SM-N2015
Magnum 210*	MX240			15X30	WPFDS-12-300150-156SM-N2015
Magnum 215*	MX245*			10X34	WPFDS-12-340100-156SM-N2015
Magnum 220*	MX255			13X34	WPFDS-12-340130-156SM-N2015
Magnum 225*	MX270			15X34	WPFDS-12-340150-156SM-N2015
Magnum 235*	MX275			10X38	WPFDS-12-380100-156SM-N2015
Magnum 240	MX285			12X38	WPFDS-12-380120-156SM-N2015
Magnum 245*	MX305				
Magnum 250	MX335				
Magnum 260	Opt. 270				
Magnum 275	Opt. 300				
Magnum 280					
Magnum 290					
Magnum 305					
Magnum 310					
Magnum 315					
Magnum 335					
Magnum 340					
Magnum 360					
Magnum 380					

*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering
New studs and hardware are included with this kit.

John Deere						
Models		Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number	
					20 or 30" Row Spacing	
6140R	6145R	6145M	10-20mm Bolts on 13.187" Bolt Circle with 11.060" Pilot Hole	74"	12X28	WPFDS-10-280120-156JY-B2075
6150M	6150R	6155M			15X28	WPFDS-10-280150-156JY-B2075
6195R	6210R	6215R			13X30	WPFDS-10-300130-156JY-B2075
7130	7200R*	7210R*			15X30	WPFDS-10-300150-156JY-B2075
7215R*	7230	7330*			10X34	WPFDS-10-340100-156JY-B2075
7400	7430*	7510			13X34	WPFDS-10-340130-156JY-B2075
7530*	7610	7630*			15X34	WPFDS-10-340150-156JY-B2075
7710	7720*	7810			10X38	WPFDS-10-380100-156JY-B2075
7820*	7830*	7920*			12X38	WPFDS-10-380120-156JY-B2075

*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering
Hardware is provided with the spacer to be used for mounting the inner wheel and spacer. The original hardware needs to be used to mount the dual wheel.



FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

3/20/2018

John Deere						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
7200R*	7210R*	7215R*	12-20mm Bolts on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/4"	12X28	WPFDS-12-280120-156JY-B2075
7230	7230R	7250R			15X28	WPFDS-12-280150-156JY-B2075
7260R	7270R	7280R			13X30	WPFDS-12-300130-156JY-B2075
7290R	7310R	7330*			15X30	WPFDS-12-300150-156JY-B2075
7430*	7530*	7630*			10X34	WPFDS-12-340100-156JY-B2075
7720*	7820*	7830*			13X34	WPFDS-12-340130-156JY-B2075
7920*	7930*	8100			15X34	WPFDS-12-340150-156JY-B2075
8110	8120	8130			10X38	WPFDS-12-380100-156JY-B2075
8200	8210	8220			12X38	WPFDS-12-380120-156JY-B2075
8225R**	8230	8235R**				
8245R**	8260R**	8270R**				
8285R**	8295R**	8300				
8310	8310R**	8320				
8320R**	8330	8335R**				
8345R**	8360R**	8370R**				
8400	8410	8420				
8430	8520	8530				

*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering

**These models have been made with 16.732" Bolt Circle and 19.685" Bolt Circle. Please verify hub before ordering

Hardware is provided with the spacer to be used for mounting the inner wheel and spacer. The original hardware needs to be used to mount the dual wheel.

New Holland						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
8670 8770 8870 8970			10-3/4" Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	74"	12X28	WPFDS-10-280120-156FW-N7516
					15X28	WPFDS-10-280150-156FW-N7516
					13X30	WPFDS-10-300130-156FW-N7516
					15X30	WPFDS-10-300150-156FW-N7516
					10X34	WPFDS-10-340100-156FW-N7516
					13X34	WPFDS-10-340130-156FW-N7516
					15X34	WPFDS-10-340150-156FW-N7516
					10X38	WPFDS-10-380100-156FW-N7516
					12X38	WPFDS-10-380120-156FW-N7516

New studs and hardware are included with this kit.



FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

3/20/2018

New Holland				
Models	Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
				20 or 30" Row Spacing
T8010* T8020* T8275* T8300* TG210 TG215* TG230 TG245* T8.275*	10-20mm Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	74"	12X28	WPFDS-10-280120-156FW-N2015
			15X28	WPFDS-10-280150-156FW-N2015
			13X30	WPFDS-10-300130-156FW-N2015
			15X30	WPFDS-10-300150-156FW-N2015
			10X34	WPFDS-10-340100-156FW-N2015
			13X34	WPFDS-10-340130-156FW-N2015
			15X34	WPFDS-10-340150-156FW-N2015
			10X38	WPFDS-10-380100-156FW-N2015
			12X38	WPFDS-10-380120-156FW-N2015

*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering
 New studs and hardware are included with this kit.

New Holland				
Models	Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
				20 or 30" Row Spacing
T8010* T8020* T8030 T8040 T8050 T8275* T8300* T8330 T8360 T8390 TG215* TG245* TG255 TG275 TG285 TG305 T8.275* T8.300 T8.320 T8.330 T8.350 T8.360 T8.380 T8.390 T8.410 T8.435	12-20mm Studs on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/4"	12X28	WPFDS-12-280120-156FW-N2015
			15X28	WPFDS-12-280150-156FW-N2015
			13X30	WPFDS-12-300130-156FW-N2015
			15X30	WPFDS-12-300150-156FW-N2015
			10X34	WPFDS-12-340100-156FW-N2015
			13X34	WPFDS-12-340130-156FW-N2015
			15X34	WPFDS-12-340150-156FW-N2015
			10X38	WPFDS-12-380100-156FW-N2015
			12X38	WPFDS-12-380120-156FW-N2015

*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering
 New studs and hardware are included with this kit.

New Holland				
Models	Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
				20 or 30" Row Spacing
T7.290 T7.315	12-22mm Studs on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/4"	12X28	WPFDS-12Q-280120-156FW-N2215
			15X28	WPFDS-12Q-280150-156FW-N2215
			13X30	WPFDS-12Q-300130-156FW-N2215
			15X30	WPFDS-12Q-300150-156FW-N2215
			10X34	WPFDS-12Q-340100-156FW-N2215
			13X34	WPFDS-12Q-340130-156FW-N2215
			15X34	WPFDS-12Q-340150-156FW-N2215
			10X38	WPFDS-12Q-380100-156FW-N2215
			12X38	WPFDS-12Q-380120-156FW-N2215

New studs and hardware are included with this kit.