



# FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

8/15/2023

AGCO, Challenger, Fendt, Massey Ferguson						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
545E	555E	565E	10-22mm Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	74-1/2"	12X28	WPFDS-10Q-280120-156AG-N2215
575E	585E	595E			15X28	WPFDS-10Q-280150-156AG-N2215
MT545BD	MT545BV	MT555BD			13X30	WPFDS-10Q-300130-156AG-N2215
MT555BV	MT555D	MT565			15X30	WPFDS-10Q-300150-156AG-N2215
MT565BD	MT565BV	MT575B			10X34	WPFDS-10Q-340100-156AG-N2215
MT575D	MT585D	MT595			13X34	WPFDS-10Q-340130-156AG-N2215
MT635	MT645*	712			15X34	WPFDS-10Q-340150-156AG-N2215
714	716	718			10X38	WPFDS-10Q-380100-156AG-N2215
720	722	724			12X38	WPFDS-10Q-380120-156AG-N2215
815**	817**	818**				
820**	822**	824**				
826**	828**	6480				
6485	6490	6495				
6497	6499	7480				
7485	7490	7495				
7499	7618	7619				
7620	7622	7624				
7626	7718	7719				
7720	7722	7724				
7726	8220	8240				
8245	8250	8260				
8450	8460	DT200A*				
RT130	RT145					

\*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering

\*\*These models need to have hub holes drilled out for larger stud installation.

New studs and hardware are included with this kit.



# FRONT WHEEL ASSIST

8/15/2023

## 20" OR 30" ROW DUAL KITS

AGCO, Challenger, Fendt, Massey Ferguson

Models	Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
				20 or 30" Row Spacing
DT160 DT180 DT180A	12-22mm Studs on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/2"	12X28	WPFDS-12Q-280120-156AG-N2215
DT200 DT200A* DT225			15X28	WPFDS-12Q-280150-156AG-N2215
DT225B DT220A DT240A			13X30	WPFDS-12Q-300130-156AG-N2215
DT250B DT275B MT645C			15X30	WPFDS-12Q-300150-156AG-N2215
MT655 MT655C MT655D			10X34	WPFDS-12Q-340100-156AG-N2215
MT655E MT665 MT665C			13X34	WPFDS-12Q-340130-156AG-N2215
MT665D MT665E MT675C			15X34	WPFDS-12Q-340150-156AG-N2215
MT675D MT675E MT685D			10X38	WPFDS-12Q-380100-156AG-N2215
MT685E 920 922			12X38	WPFDS-12Q-380120-156AG-N2215
924 926 927				
930 933 936				
939 8270 8280				
8470 8480 8650				
8660 8670 8680				
8690 8727 8730				
8732 8735 8737				

\*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering

New studs and hardware are included with this kit.

### Case-IH

Models	Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
				20 or 30" Row Spacing
7110 7120 7130 7140 7150 7210 7220 7230 7240 7250	10-3/4" Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	77-3/4"	12X28	WPFDS-10-280120-156SM-N7516
			15X28	WPFDS-10-280150-156SM-N7516
			13X30	WPFDS-10-300130-156SM-N7516
			15X30	WPFDS-10-300150-156SM-N7516
			10X34	WPFDS-10-340100-156SM-N7516
			13X34	WPFDS-10-340130-156SM-N7516
			15X34	WPFDS-10-340150-156SM-N7516
			10X38	WPFDS-10-380100-156SM-N7516
			12X38	WPFDS-10-380120-156SM-N7516

New studs and hardware are included with this kit.



# FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

8/15/2023

<b>Case-IH</b>						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
8910      8920      8930 8940      8950	10-20mm Studs on 13.187" Bolt Circle with 11.060" Pilot Hole		74-1/2"	12X28	WPFDS-10-280120-156SM-N2015	
				15X28	WPFDS-10-280150-156SM-N2015	
				13X30	WPFDS-10-300130-156SM-N2015	
				15X30	WPFDS-10-300150-156SM-N2015	
				10X34	WPFDS-10-340100-156SM-N2015	
				13X34	WPFDS-10-340130-156SM-N2015	
				15X34	WPFDS-10-340150-156SM-N2015	
				10X38	WPFDS-10-380100-156SM-N2015	
12X38	WPFDS-10-380120-156SM-N2015					

New studs and hardware are included with this kit.

<b>Case-IH</b>					
Models		Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
					20 or 30" Row Spacing
Magnum 180*	MX180	10-20mm Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	74"	12X28	WPFDS-10-280120-156SM-N2015
Magnum 190*	MX200			15X28	WPFDS-10-280150-156SM-N2015
Magnum 200*	MX210*			13X30	WPFDS-10-300130-156SM-N2015
Magnum 210*	MX215*			15X30	WPFDS-10-300150-156SM-N2015
Magnum 215*	MX220			10X34	WPFDS-10-340100-156SM-N2015
Magnum 225*	MX230*			13X34	WPFDS-10-340130-156SM-N2015
Magnum 235*	MX245*			15X34	WPFDS-10-340150-156SM-N2015
Magnum 245*				10X38	WPFDS-10-380100-156SM-N2015
		12X38	WPFDS-10-380120-156SM-N2015		

\*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering

New studs and hardware are included with this kit.



# FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

8/15/2023

<b>Case-IH</b>					
Models		Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
					20 or 30" Row Spacing
Magnum 180*	MX210*	12-20mm Studs on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/4"	12X28	WPFDS-12-280120-156SM-N2015
Magnum 190*	MX215*			15X28	WPFDS-12-280150-156SM-N2015
Magnum 200*	MD230*			13X30	WPFDS-12-300130-156SM-N2015
Magnum 210*	MX240			15X30	WPFDS-12-300150-156SM-N2015
Magnum 215*	MX245*			10X34	WPFDS-12-340100-156SM-N2015
Magnum 220*	MX255			13X34	WPFDS-12-340130-156SM-N2015
Magnum 225*	MX270			15X34	WPFDS-12-340150-156SM-N2015
Magnum 235*	MX275			10X38	WPFDS-12-380100-156SM-N2015
Magnum 240	MX285			12X38	WPFDS-12-380120-156SM-N2015
Magnum 245*	MX305				
Magnum 250	MX335				
Magnum 260	Opt. 270				
Magnum 275	Opt. 300				
Magnum 280					
Magnum 290					
Magnum 305					
Magnum 310					
Magnum 315					
Magnum 335					
Magnum 340					
Magnum 360					
Magnum 380					

\*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering  
New studs and hardware are included with this kit.

<b>John Deere</b>						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
6140R	6145R	6145M	10-20mm Bolts on 13.187" Bolt Circle with 11.060" Pilot Hole	74"	12X28	WPFDS-10-280120-156JY-B2075
6150M	6150R	6155M			15X28	WPFDS-10-280150-156JY-B2075
6195R	6210R	6215R			13X30	WPFDS-10-300130-156JY-B2075
7130	7200R*	7210R*			15X30	WPFDS-10-300150-156JY-B2075
7215R*	7230	7330*			10X34	WPFDS-10-340100-156JY-B2075
7400	7430*	7510			13X34	WPFDS-10-340130-156JY-B2075
7530*	7610	7630*			15X34	WPFDS-10-340150-156JY-B2075
7710	7720*	7810			10X38	WPFDS-10-380100-156JY-B2075
7820*	7830*	7920*			12X38	WPFDS-10-380120-156JY-B2075

\*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering  
Hardware is provided with the spacer to be used for mounting the inner wheel and spacer. The original hardware needs to be used to mount the dual wheel.



# FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

8/15/2023

John Deere						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
7200R*	7210R*	7215R*	12-20mm Bolts on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/4"	12X28	WPFDS-12-280120-156JY-B2075
7230	7230R	7250R			15X28	WPFDS-12-280150-156JY-B2075
7260R	7270R	7280R			13X30	WPFDS-12-300130-156JY-B2075
7290R	7310R	7330*			15X30	WPFDS-12-300150-156JY-B2075
7430*	7530*	7630*			10X34	WPFDS-12-340100-156JY-B2075
7720*	7730*	7820*			13X34	WPFDS-12-340130-156JY-B2075
7830*	7920*	7930*			15X34	WPFDS-12-340150-156JY-B2075
7R210	7R230	7R250			10X38	WPFDS-12-380100-156JY-B2075
7R270	7R290	7R310			12X38	WPFDS-12-380120-156JY-B2075
7R330	7R350	8100				
8110	8120	8130				
8200	8210	8220				
8225R**	8230	8235R				
8245R**	8260R	8270R**				
8285R	8295R**	8300				
8310	8310R	8320				
8320R**	8330	8335R**				
8345R**	8360R	8370R**				
8400	8400R	8410				
8420	8430	8520				
8530	8R230**	8R250**				
8R280**	8R310**	8R340**				
8R370**	8R410**					

\*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering

\*\*These models have been made with 16.732" Bolt Circle and 19.685" Bolt Circle. Please verify hub before ordering

Hardware is provided with the spacer to be used for mounting the inner wheel and spacer. The original hardware needs to be used to mount the dual wheel.



# FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

8/15/2023

<b>John Deere</b>						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
8225R**	8235R**	8245R**	12-20mm Bolts on 19.685" Bolt Circle with 17.651" Pilot Hole	74-1/4"	10X34	WPFDS-12J-340100-156JY-B2075
8260R**	8270R**	8285R**			13X34	WPFDS-12J-340130-156JY-B2075
82395R**	8310R**	8320R**			15X34	WPFDS-12J-340150-156JY-B2075
8335R**	8345R**	8360R**			10X38	WPFDS-12J-380100-156JY-B2075
8370R**	8400R**	8R230**			12X38	WPFDS-12J-380120-156JY-B2075
8R250**	8R280**	8R310**				
8R340**	8R370**	8R410**				

\*\*These models have been made with 16.732" Bolt Circle and 19.685" Bolt Circle. Please verify hub before ordering  
Hardware is provided with the spacer to be used for mounting the inner wheel and spacer. The original hardware needs to be used to mount the dual wheel.

<b>New Holland</b>						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
8670 8770 8870 8970			10-3/4" Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	74"	12X28	WPFDS-10-280120-156FW-N7516
					15X28	WPFDS-10-280150-156FW-N7516
					13X30	WPFDS-10-300130-156FW-N7516
					15X30	WPFDS-10-300150-156FW-N7516
					10X34	WPFDS-10-340100-156FW-N7516
					13X34	WPFDS-10-340130-156FW-N7516
					15X34	WPFDS-10-340150-156FW-N7516
					10X38	WPFDS-10-380100-156FW-N7516
12X38	WPFDS-10-380120-156FW-N7516					

New studs and hardware are included with this kit.

<b>New Holland</b>						
Models			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number
						20 or 30" Row Spacing
T8010* T8020* T8275* T8300* TG210 TG215* TG230 TG245* T8.275*			10-20mm Studs on 13.187" Bolt Circle with 11.060" Pilot Hole	74"	12X28	WPFDS-10-280120-156FW-N2015
					15X28	WPFDS-10-280150-156FW-N2015
					13X30	WPFDS-10-300130-156FW-N2015
					15X30	WPFDS-10-300150-156FW-N2015
					10X34	WPFDS-10-340100-156FW-N2015
					13X34	WPFDS-10-340130-156FW-N2015
					15X34	WPFDS-10-340150-156FW-N2015
					10X38	WPFDS-10-380100-156FW-N2015
12X38	WPFDS-10-380120-156FW-N2015					

\*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering  
New studs and hardware are included with this kit.



# FRONT WHEEL ASSIST 20" OR 30" ROW DUAL KITS

8/15/2023

<b>New Holland</b>						
RIM & WHEEL			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number 20 or 30" Row Spacing
T8010*	T8020*	T8030	12-20mm Studs on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/4"	12X28	WPFDS-12-280120-156FW-N2015
T8040	T8050	T8275*			15X28	WPFDS-12-280150-156FW-N2015
T8300*	T8330	T8360			13X30	WPFDS-12-300130-156FW-N2015
T8390	TG215*	TG245*			15X30	WPFDS-12-300150-156FW-N2015
TG255	TG275	TG285			10X34	WPFDS-12-340100-156FW-N2015
TG305	T8.275*	T8.300			13X34	WPFDS-12-340130-156FW-N2015
T8.320	T8.330	T8.350			15X34	WPFDS-12-340150-156FW-N2015
T8.360	T8.380	T8.390			10X38	WPFDS-12-380100-156FW-N2015
T8.410	T8.435				12X38	WPFDS-12-380120-156FW-N2015

\*These models have been made with a 10 Hole and 12 Hole hub. Please verify hub before ordering

New studs and hardware are included with this kit.

<b>New Holland</b>						
RIM & WHEEL			Bolt Pattern	Flange to Flange	Wheel Size	Wold Part Number 20 or 30" Row Spacing
T7.290	T7.315		12-22mm Studs on 16.732" Bolt Circle with 14.620" Pilot Hole	74-1/4"	12X28	WPFDS-12Q-280120-156FW-N2215
					15X28	WPFDS-12Q-280150-156FW-N2215
					13X30	WPFDS-12Q-300130-156FW-N2215
					15X30	WPFDS-12Q-300150-156FW-N2215
					10X34	WPFDS-12Q-340100-156FW-N2215
					13X34	WPFDS-12Q-340130-156FW-N2215
					15X34	WPFDS-12Q-340150-156FW-N2215
					10X38	WPFDS-12Q-380100-156FW-N2215
					12X38	WPFDS-12Q-380120-156FW-N2215

New studs and hardware are included with this kit.